



Spare parts list

<u>Description</u>	<u>Peddinghaus nr.</u>	<u>Ridgid Cat.</u>	
<u>Spindle including Spring, Washers and Pin</u>			
	Spindle 100	10203 114 0000	90006
	Spindle 120/125	10204 114 0000	90016
	Spindle 140/150	10205 114 0000	90026
	Spindle 160/180	10206 114 0000	90036

Spindle Lever pack of 3



Spindle lever 100	10203 114 1200	90046
Spindle lever 120/125	10204 114 1200	90056
Spindle lever 140/150	10205 114 1200	90066
Spindle lever 160/180	10206 114 1200	90076

Spindle Nut



Spindle Nut 100	10803 113 0000L	90086
Spindle Nut 120/125	10804 113 0000L	90096
Spindle Nut 140/150	10805 113 0000L	90106
Spindle Nut 160/180	10806 113 0000L	90116

Spindle lever rings



Ring for 100	10203 114 1202	90126
Ring for 120/125	10204 114 1202	90136
Ring for 140/150	10205 114 1202	90146
Ring for 160/180	10206 114 1202	90156



Spare Parts List

	<u>Description</u>	<u>Peddinghaus nr.</u>	<u>Ridgid Cat.</u>
<u>Locking handle</u>			
	Spannhebel	10324 111 9905	10166
<u>Locking handle with excentric bolt adjustment</u>			
	Locking handle	10324 111 0200	90176
	Handle Peddi Lift	79350 251 2080	90186
<u>Fixed lower jaw including Rivet</u>			
	Lower Jaw 2"	11052 111 0300	90196
	Lower Jaw 3"	11053 111 0300	90206
	Lower Jaw 4"	11054 111 0300	90216
<u>Upper jaw including Rivet</u>			
	Upper Jaw 2"	11052 112 0200	90226
	Upper Jaw 3"	11053 112 0300	90236
	Upper Jaw 4"	11054 112 0300	90246



Peddinghaus

Ersatzteile Liste

<u>Description</u>	<u>Peddinghaus nr.</u>	<u>Ridgid Cat.</u>
<u>Locking hook and Rivet</u>		
 Locking hook / Rivet	11052 199 108A	90256
<u>Locating Screw</u>		
Locating Screw 100	10213 111 0300	90266
Locating Screw 120	10214 111 0300	90276
Locating Screw 140/160	10215 111 0300	90286
Locating Screw 180	10216 111 0300	90296